
# ToMaTo Programmable Devices

## ToMaTo, Topology Management Tool

ToMaTo is topology-oriented, i.e. users build topologies for their experiments.



#### **Devices**

- produce and consume data
- can run software

#### Three kinds of devices

- KVM devices
- OpenVZ devices
- Programmable devices

#### **Connectors**

- forward and manipulate data
- connect devices

#### Two kinds of connectors

- VPN networks
- External networks

# Programmable devices

Programmable devices run scripts written in Repy, a sandboxed Python dialect. Using these devices, networking data can be read and written as raw Ethernet packages.

#### Difference between Repy and Python

- No global variables. Instead Repy has a dictionary mycontext that can be used to store global variables.
- No user input via input or raw\_input
- Some Python builtins are not available. The most important are:
  - import and reload, Repy does not allow library loading
  - o print, USE echo("message") instead
  - input, raw\_input, eval and execfile
  - lambda and yield
  - hasattr, getattr and setattr
- Parameters to the script are passed as callargs

## Script library: tomatolib

The library is part of the ToMaTo source code and located at Github. It contains the following:

Implementations of common Internet protocols (some are stubs)

Example Repy scripts

Utility methods for Repy scripts

Makefile to include libraries in scripts and build combined script

Library files can be found in the lib directrory and can be included like in the C programming language

```
#include <some_file/in_lib.repy>
def your_code(comes, here):
...
```

Build your final output script using these steps:

- 1. Put your code in the src directory
- 2. Call make in the base directory
- Find your output script in the build directory

# **Packet reading**

#### Reading from one device

```
1 packet = tuntap_read("eth0", timeout=None)
```

#### **Timeout values**

- timeout=T waits at most for T seconds for a packet, otherwise returns None
- timeout=0.0 returns packet (or None) immediately, no timeout
- timeout=None returns when a packet has been received, infinite timeout

#### Reading from all devices at once

```
1 (dev, packet) = tuntap_read_any(timeout=None)
```

#### **Default reading loop**

```
while True:
    try:
    (dev, packet) = tuntap_read_any(timeout=None)
    if packet:
        handle(dev, packet)
        except Exception, e:
        print_exc(e)
```

# **Packet sending**

#### Sending on one device

```
1 tuntap_send("eth0", packet)
```

#### Sending on all devices

```
1 for dev in tuntap_list():
2  send(dev, packet)
```

#### Sending and receiving (simple switch example)

```
1 #include <layer2/ethernet_proto.repy>
  mac_table = {}
  while True:
     (dev, packet) = tuntap_read_any(timeout=None)
     ether = ethernet decode(packet)
    mac table[ether.src] = dev
     dst = mac table.get(ether.dst)
     if dst:
10
11
       tuntap send(dst, packet)
12
     else:
13
       for dst in tuntap_list():
14
         if dst != dev:
           tuntap_send(dst, packet)
15
```

# Working with protocols - dissecting headers

#### Packets are strings

- packet[index] is one character (one byte)
- len(packet) is the size of a packet
- packet[start:end] is a byte range from start to end-1
- ord(char) converts a character to a number
- chr(num) converts a number to a character

#### **Example: IP**

```
# This is only the IP header

# Source and destination address are 4 bytes each starting at bytes 12 and 16

# Source and destination address are 4 bytes each starting at bytes 12 and 16

# IP header length is last 4 bits of the first byte

# IP header length counts length in 4-byte blocks
# First 5 blocks are normal header, rest are option headers

# Options = []
# Options.append(packet[4*i:4*i+4])

# After the header comes the payload
# After the header comes the payload
# Payload = packet[ihl*4:]
```

# Packing and unpacking binary data using struct

#### **Decoding binary data**

```
1 (byte1, byte2, int1, int2) = struct.unpack("!BBHH", packet[0:6])
```

#### **Encoding binary data**

```
1 packet = struct.pack("!BBHH", byte1, byte2, int1, int2)
```

#### Struct codes

- ! means network byte order, must be first character
- Each character stands for one field
  - **B** is a number that takes 1 byte (**B**yte)
  - H is a number that takes 2 bytes (Half-integer)
  - I is a number that takes 4 bytes (Integer)
  - Q is a number that takes 8 bytes
- Uppercase is unsigned, lowercase is signed

See the python struct documentation for more info.

# Tips & Tricks

Code sharing: Share your code with others on Github to improve the library and to get feedback.

**Performance:** Code that uses struct to convert binary data to numbers is a faster but the fastest code avoids convertions.

**Exception handling:** Wrap the per-packet code in a try-except block, otherwise the script will abort on an error.

**80-20 rule:** 80% of the functionality of a protocol is implemented in 20% of its code, and vice versa. Most protocols have optional features that are not needed in most cases.

Arguments: Scripts can take arguments, no need to write different scripts just to have different addresses.

# **Obtaining and contributing**

#### How to get ToMaTo

ToMaTo is Open-Source! It can be simply downloaded from the Github page. There is also a step-by-step tutorial on how to setup ToMaTo in a testbed. ToMaTo includes some nice features that make it pretty easy to install it in an experimental facility:

- All components packaged for debian (updates come automatically)
- Multiple authentication plugins: LDAP, htaccess, SQL-Database, Planet-Lab, ...
- Automatic checks and problem reports for the ToMaTo hosts

#### How to contribute to ToMaTo

As an Open-Source project ToMaTo is open for hints and contributions.

- Github offers an easy way to fork the project and offer contributions as pull requests
- The wiki is publically editable so everyone can help by adding to the documentation
- The issue tracking system can be used for bug reports and feature requests